

Instructions for downloading and copying JT40 Display update files to flash drive.

- Start with a 2 GB flash drive or larger.
- Flash drive must be free of other files or folders.
- Download zipped file from <https://subsite.com/documents/JT40-AT40-Display.zip>



and copy to computer.

- Extract zipped file to computer and copy files and folders to flash drive as seen in the photo below.

Name	Date modified	Type	Size
LinXTmpData	7/13/2018 11:21 AM	File folder	
canfix	6/8/2018 1:16 PM	SH File	1 KB
cc-auto	6/8/2018 1:16 PM	SH File	4 KB
Commander.tgz	6/8/2018 1:16 PM	TGZ File	1,668 KB
complete	6/8/2018 1:16 PM	PNG File	17 KB
fonts.tgz	6/8/2018 1:16 PM	TGZ File	9,975 KB
LinX-Base_XA_device_v2.0.0_install	6/8/2018 1:16 PM	SH File	2 KB
logo	6/8/2018 1:16 PM	PNG File	14 KB
StartupGui	6/8/2018 1:16 PM	File	2 KB
sync_fix	6/8/2018 1:16 PM	SH File	1 KB
VERSION_3.02	6/8/2018 1:16 PM	O2 File	1 KB

- Insert flash drive into appropriate USB port to start display update.
- Once display is updated, use Field Scout™ to update the Commander 7 CAN bridge.
- For additional information, view this video on updating the JT40/AT40 All Terrain Commander 7 display.
[Updating Your JT40 Commander 7 Integrated Display Video](#)
Once display and CAN is updated, use the “Adding Scout View™ to Commander™ 7 Display” if desired.